

Computer System Architecture
COMP201Th
Unit: 2
Basic Computer Organization and Design

Lecture: 1

Computer Registers and Bus System

The organization of the computer is defined by its internal registers, the timing and control structure, and the set of instructions that it uses. Computer can be instructed about the specific sequence of operations it must perform i.e. by means of a program.

Program: set of instructions that specify the operations, operands and sequence by which processing has to occur.


Instruction: a binary code that specifies a sequence of micro-operations for the computer.

The computer reads each instruction from memory and places it in a control register. The control then interprets the binary code of the instruction and proceeds to execute it by issuing a sequence of micro-operations.

Instruction Code: group of bits that instruct the computer to perform specific operation.


Instruction code is usually divided into two parts:

- **Operation Code (Opcode):**
 - Group of bits that define the operation
 - E.g. add, subtract, multiply, shift, complement
 - No. of bits required for opcode depends on no of operations available in computer.
- **Address (Operand):**
 - Specifies the location of operands (registers or memory words).
 - Memory words are specified by their address.
 - Registers are specified by their k-bit binary code.
 - K-bit address $\geq 2^k$ registers



Stored Program Organization:

The simplest way to organize a computer is to have one processor register and an instruction code format with two parts. The first part specifies the operation to be performed and the second specifies an address. Figure below shows the stored program organization.



- Instructions are stored in one section of memory and data in another.
- For a memory unit with 4096 words we need 12 bits to specify an address since $2^{12}=4096$.
- **Accumulator (AC):** Computers that have a single-processor register usually assign to it the name accumulator. The operation is performed with the memory operand and the content of AC.

Computer Registers:

Need for Computer Registers:

- The need of the registers in computer is for:
 - Instruction sequencing needs a counter to calculate the address of the next instruction after execution of the current instruction is completed (PC).
 - Necessary to provide a register in the control unit for storing the instruction code after it is read from memory (IR).
 - Needs processor registers for manipulating data (AC and TR) and a register for holding a memory address (AR).

List of Registers for Basic Computer:

Register symbol	Number of bits	Register name	Function
<i>DR</i>	16	Data register	Holds memory operand
<i>AR</i>	12	Address register	Holds address for memory
<i>AC</i>	16	Accumulator	Processor register
<i>IR</i>	16	Instruction register	Holds instruction code
<i>PC</i>	12	Program counter	Holds address of instruction
<i>TR</i>	16	Temporary register	Holds temporary data
<i>INPR</i>	8	Input register	Holds input character
<i>OUTR</i>	8	Output register	Holds output character




Fig. Basic Computer Registers and Memory

- **Memory Address Register (AR):** 12 bits; holds address for memory.
- **Program Counter (PC):** 12 bits; holds address of the next instruction to be read from memory after the current instruction is executed.
- **Data Register(DR):** 16 bits; holds operand read from memory.

- **Accumulator Register (AC):** 16bits; general purpose processing register.
- **Instruction Register (IR):** 16bits; instructions read from memory are placed there.
- **Temporary Register (TR):** 16 bits; used for holding temporary data during processing.
- **Input Register (INPR):** 8bits; INPR receives an 8 bit character from an input device.
- **Output Register (OUTR):** 8bits, OUTR holds an 8-bit character for an output device.

Common Bus System:

The basic computer has eight registers, a memory unit and a control unit. Paths must be provided to transfer information from one register to another and between memory and registers.

A more efficient scheme for transferring information in a system with many registers is to use a common bus. The connection of the registers and memory of the basic computer to a common bus system is shown below:




Fig. Basic Computer registers connected to a common bus

The outputs of seven registers and memory are connected to the common bus. The specific output that is selected for the bus lines at any given time is determined from the binary value of the selection variables S_2 , S_1 and S_0 . The number along each output shows the decimal equivalents of the required binary selection.

e.g. the number along the output of DR is 3. The 16-bit outputs of DR are placed on the bus lines when $S_2S_1S_0 = 011$.

The lines from the common bus are connected to the inputs of each register and the data inputs of the memory. The particular register whose LD (Load) input is enabled receives the data from the bus during the next clock pulse transition.

- The memory receives the contents of the bus when its write input is activated. The memory places its 16-bit output onto the bus when the read input is activated and $S_2S_1S_0 = 111$.
- Two registers AR and PC, have 12 bits each since they hold a memory address. When the contents of AR or PC are applied to the 16-bit common bus, the four most significant bits are set to 0's.
- Five registers have three control inputs: LD (Load), INR (increment) and CLR (clear).
- The input data and output data of the memory are connected to the common bus, but the memory address is connected to AR. Therefore, AR must always be used to specify a memory address.
- The 16 inputs of AC come from an adder and logic circuit. This circuit has three sets of inputs:
 - One set of 16-bit inputs come from the outputs of AC.
 - Another set of 17-bit inputs come from the data register DR.
 - The result of an addition is transferred to AC and the end carry-out of the addition is transferred to flip-flop E (extended AC bit).
 - A third set of 8-bit inputs come from the input register INPR.
- The content of any register can be applied onto the bus and an operation can be performed in the adder and logic circuit during the same clock cycle.